

## Personal information

Delivery set includes a sticker with following data:

- device main unit serial number
- activation code to sign up in StarLine account
- service code
- emergency disarm code



Remove protection layer from the sticker carefully.  
Do not use metal and other sharp items to avoid occasional erasing a printed information under protection layer.

- ! **Do not share emergency disarm code and service code with anybody to avoid your vehicle security breach!**

Due to security reasons the service and emergency disarm codes are generated randomly at factory, never stored in any database and therefore cannot be recovered once lost!  
A system main unit with lost service code and emergency disarm code cannot be normally used and must be replaced to a new one. Strongly recommend to copy it in a safe place and record in StarLine mobile app: **“Settings” — “General information” — “Device codes”**

## StarLine.online web service and mobile app

StarLine system can be remotely controlled and monitored on the [starline.online](#) web tracking platform and StarLine mobile app with life time free subscription.

Make sure that a proper local SIM card with active balance, internet traffic and permission to operate with M2M smart devices is installed and configured at installation.

SIM card boot PIN code must be disabled prior to inserting into the main unit.

Check out if the cellular standards and bands supported by the built-in modem in corresponding hardware version conform to your local operator bands (find details in technical specification).

1. Download StarLine 2 mobile app from your phone store (App Store, Google Play, Huawei AppGallery) or browse [starline.online](#) web tracking service
2. Register a new or sign in to existing StarLine account
3. Go to **“Device adding”** (“+” button) menu on the main screen, select **“Add new device”** — **Next** — **“GSM module, alarm system, smart tracker”** — **“Use activation code”**
4. Enter the activation code printed on attached sticker
5. System will be registered on server and appear in device list on the main screen

